

Pack your box: AMBIENT CULTURED SPECIMENS

UN3373 BIOLOGICAL SUBSTANCES CATEGORY B



SCAN

- 1** Choose either 10 lb ambient box, or 20 lb ambient box.
- 2** If using a 10 lb box, place one room-temperature gel pack flat on the bottom of the Styro. If using 20 lb box, place three room-temperature gel packs flat on the bottom of the Styro.
- 3** Package the specimen in the infectious container.
 - Place specimen in a clear ziplock bag with absorbent sheet; seal. (One specimen per bag.)
 - Place sealed specimen bag in bubble wrap bag, remove strip, and seal.
 - Insert into transport container; tighten cap. (Max 2 bubble wrapped specimens).
- 4** Place container into ambient biohazard bag labeled with the “C” sticker and seal.
- 5** Insert specimen paperwork in the outer pocket of the biohazard bag (do not place inside with the specimen).
- 6** Place bagged container into Styro.
- 7** If using a 10 lb box, place one room-temperature gel pack flat on the top of the bag in the Styro. If using 20 lb box, place three room-temperature gel packs on top of the bag in the Styro. Ensure that at least 2 inches of space are available inside the Styro.
- 8** Replace the Styro lid ensuring there is a tight seal, and place blue “C” sticker onto the lid of the Styro.
- 9** Use only packaging tape to close box per the closing instructions. Overlap the sides by 2 inches to ensure the container is sealed. Place blue “C” sticker on the outside of the box.

